

ROBUST LED SPOTLIGHT

OPERATION

HIGH > OFF
[Press 3 seconds for LOW, further long press 2 seconds for 2Hz FLASHING]
[Switch the safety lock downwards to prevent unwanted ON/OFF activation]

BULB TYPE 1 x XP-G2 Cree White LED

BATTERY TYPE

3 x 1.5V C Alkaline Batteries [Not Included]

ACCESSORIES

Carrying Strap & Shoulder Strap

ST7F

Ø75 mm x 146 mm x 160 mm


WEIGHT

BATTERY REPLACEMENT


- 1. Open battery case cover and remove it from the unit
- 2. Remove battery cartridge.
- 3. Remove old batteries and replace with three new 1.5V C alkaline batteries according to the polarity labels.
- 4. Glide back the battery cartridge into the unit on its own track (don't force).
- 5. Replace battery case cover back on.

BULB REPLACEMENT

LED never needs to be replaced.



Flashing mode specifications cannot be measured by ANSI FL1 standard. Flashing mode runtime is based on measurement of battery capacity change only.





[Not Included]



Rescue Missions




Searching



Campsite



Workshop



■ Repair Spot